




Wisząca 100



- (PL) Instrukcja montażu
- (D) Aufbauanleitung
- (GB) Assembly instruction
- (SK) Návod na montáž













- Karta gwarancyjna
- der Garantieschein
- Guarantee certificate
- Záručný list






Akcesoria - Accessories - die Accessoires

W x2	M. x30	B2 8x35mm x20	C x12	D x12
E1 x4	E2 x4	W1 3,5x16 x22	 x1	H x2


I





II





III






IV












V



VI



VII



VIII

